



FOUNTAIN K TO RENDER K CONVERSION INSTRUCTIONS



First unscrew the grip section from the body removing any ink dispensers (ink cartridges / converters).

Use the conversion tool to push metal plug into the bottom of the body of the pen. The metal spacer usually does not need to be completely threaded onto the conversion tool in order to get the spacer to the bottom of the body. However, if you are having issues getting the metal spacer to the bottom of the pen body, then lightly thread the metal spacer onto the conversion tool and twist to the right while pushing the metal spacer to the bottom of the body.



METAL SPACER PLACEMENT:



PILOT G2 REFILL SETUP

Place the G2 spring on to the Pilot G2 refill, then place the refill inside of the body of the pen.



REFILL AND SPRING IN THE PEN BODY:



SCHMIDT PARKER STYLE REFILL SETUP

Drop the delrin spacer into the body of the pen, then place the standard spring on to the Schmidt refill. Put the refill inside of the body of the pen.



REFILL, SPACER AND SPRING IN THE PEN BODY:



Finally, screw the grip section onto the body.

