





REFILL INSTALLATION INSTRUCTIONS

- 1 Unscrew front pen body
- 2 Place spring on chosen refill and place into front body
- 3 Replace front pen body (hand tighten only)



The EDK is an awesome machined pen designed to be carried and used on a daily basis. Included with the EDK are a spring and a Schmidt P8126 ink cartridge. Parker compatible refills, like the Fisher Space Pen PR refill, work too. To clean your pen, wipe it down with a soft cloth, using mild detergent or alcohol. Never use abrasives or harsh chemicals to clean your EDK, as it may damage the surface. The aluminum versions of the EDK need no special treatment to maintain the anodized or tumbled finishes. The brass and copper versions of the EDK are designed to be left to age naturally, giving your pen a hard-earned patina. Every scuff and ding your EDK experiences only adds to its character and should be appreciated. The EDK is not a toy and should not be used by children as small parts may cause choking. We are not responsible for any damage caused by the misuse of the EDK, but may claim partial credit if something really cool happens as a result. Go forth, climb mountains, make stuff, and record it all along the way for others to enjoy. And, as always, all of our products are designed and manufactured by us, in the USA.



**Compatible Refills:**  
Schmidt P8126 Capless Rollerball  
Parker Style Ballpoint

**Aluminum Weight:** 28.8g / 1.015 oz  
**Brass Weight:** 60.3g / 2.127 oz  
**Copper Weight:** 62.7g / 2.211 oz

