



RENDER **K**

REFILL INSTALLATION INSTRUCTIONS

- 1 Unscrew front pen body
- 2 Place spring on chosen refill and place into front body
- 3 Replace front pen body (hand tighten only)

The RENDER K is designed to work with either (A) rollerball style refills (Pilot G2 refill included) or (B) Parker ballpoint compatible refills (including the Fisher Space Pen PR refill). To clean your pen, wipe it down with a soft cloth, using mild detergent or alcohol. Never use abrasives or harsh chemicals to clean your RENDER K, as it may damage the surface. The aluminum version of the RENDER K needs no special treatment to maintain the anodized finish. The copper and brass versions of the RENDER K can be polished or left to age naturally. The RENDER K is not a toy and should not be used by children as small parts may cause choking. We are not responsible for any damage caused by the misuse of the RENDER K. And remember, always draw cool stuff, run away from monsters, and always make friends with dinosaurs and robots.



Compatible Refills:
Pilot G2 Rollerball (Select 110mm Refills)
Parker Style Ballpoint

Aluminum Weight: 28.4g / 1.00 oz
Brass Weight: 76.9g / 2.71 oz
Copper Weight: 78.2g / 2.76 oz

